


# FIXED CRANE AND HOIST SAFETY

 Operate equipment only if you have been properly trained on the use and inspection.

 Inspect equipment and slings on daily basis. Make sure all controls, brakes and other devices are operating correctly.

 Never operate equipment that is not operating properly.


 Never use slings that show signs of damage or defects.


 Never stand or walk under a load, whether it is moving or stationary.

 Maintain a safe distance from loads.

 Never carry a load over workers.

 Always warn others of moving and approaching loads.

 If a load appears to be slung improperly, lower it and make adjustments immediately.

 Avoid walking with a load and guiding the load with your hands. Maintain a safe distance and use a tag line to guide loads.

